



Sample Submission



Sample quality is vital for efficient, reliable and reproducible biomarker measurements. It is therefore essential that samples arrive at the ACS Biomarker lab in excellent condition. In this technote you find some tips and tricks and guidelines for efficient sample submission and shipment.

Tubes

- ⚡ Use the correct tubes
 - **RNA**
1.5mL Eppendorf tubes
 - **Protein**
1,5mL Eppendorf tubes or
1.0mL FluidX tubes
- ⚡ Make sure labeling is correct
- ⚡ Make sure labeling is not lost during shipment

Shipment Instructions

- ⚡ Contact ACS Biomarker to time shipment
- ⚡ Ship samples preferably on Monday or Tuesday
- ⚡ Make use of a reliable courier
- ⚡ Add plenty of dry ice
- ⚡ Add a hard copy with box numbers and sample numbers
- ⚡ Provide ACS Biomarker with the tracking number

Sample Submission Form

On our website, you can download a sample submission form. Please complete the form and send it to: info@acsbiomarker.com. Please also send a hardcopy together with the samples,

Shipment Address

ACS Biomarker BV
IWO, third floor, Lab 192
Meibergdreef 39
1105 AZ
Amsterdam
The Netherlands
Tel. +31 20 566 54 58